
Trummor &Orgel

STAGEPLOT AND TECHNICAL RIDER UPDATED MARCH 22, 2016



BACKLINE	2
CHANNEL INPUT LIST	3
VIDEO INPUT/OUTPUT	3

ANDERS LJUNGGREN +46 70 4735107, INFO@TRUMMORORGEL.COM

WWW.TRUMMORORGEL.COM WWW.FACEBOOK.COM/TRUMMORORGEL WWW.SOUNDCLOUD.COM/TRUMMORORGEL



STAGEPLOT AND TECHNICAL RIDER UPDATED MARCH 22, 2016

BACKLINE

NORMALLY PROVIDED BY TRUMMOR & ORGEL, IF NOTHING ELSE IS AGREED.

DRUM KIT: JAZZ KIT (LUDWIG DOWN BEAT 60S)

- BASS DRUM 20"
- SNARE DRUM 14"
- MOUNTED 12" TOM (ON BASS DRUM)
- FLOOR TOM 14"
- 1 SET 14" HI-HAT CYMBALS (PAISTE 505 MEDIUM)
- 1 20" CRASH RIDE (ZILDJIAN K MEDIUM THIN)
- 1 20" VINTAGE SIZZLE RIDE CYMBAL (ZILDJIAN AVEDIS)
- 1 16" CRASH CYMBAL (ZILDJIAN DARK MEDIUM THIN)
- BASS DRUM KICK PEDAL
- 3 VINTAGE CYMBAL STANDS
- ADJUSTABLE DRUM CHAIR
- BENCH OR STAND FOR PORTABLE BACKTRACK UNIT
- BENCH OR STAND FOR DVD PLAYER
- (CARPET UNDER THE KIT IF NEEDED)

ORGAN: HAMMOND ORGAN

- HAMMOND ORGAN M102 WITH BASS PEDALS
- ORGAN BENCH
- ROLAND SPACE ECHO RE-201 (SIDECHAINED FROM ORGAN)
- BENCH OR STAND FOR ROLAND SPACE ECHO
- DELAY PEDAL (SIDECHAINED FROM ORGAN)

AMPLIFIERS & MISCELLANEOUS

- 2-SPEED LESLIE 251 SPEAKER (OR 122 OR 147)
- VOX AC4 AMPLIFIER (FOR SPACE ECHO)
- BASS AMP FOR OVERDRIVE BASS SIGNAL
- LESLIE CONNECTION CABLES
- 4 INSTRUMENT JACKS (TELE CABLES)
- 1-TO-2 MONO INSTRUMENT JACK (TELE PLUG)
- HDMI CABLE
- TWO STEREO RCA PLUGS FOR PORTABLE BACKTRACKS UNIT
- VIDEO PROJECTOR (>3000 ANSILUMEN)
- VIDEO PROJECTION SCREEN AND FLOOR STAND



CHANNEL INPUT LIST

CH.:	INPUT:	INSERT	STAND	DESIRED MICS:
01.	KICK			STD DRUM KIT MIC
02.	SNARE			STD DRUM KIT MIC
03.	HI-HAT			STD DRUM KIT MIC
04.	TOM			STD DRUM KIT MIC
05.	FLOOR TOM			STD DRUM KIT MIC
06.	OVERHEAD L			STD DRUM KIT MIC
07.	OVERHEAD R			STD DRUM KIT MIC
08.	LESLIE BASS	REVERB		SENNHEISER-421 OR STD BASS MIC
09.	LESLIE TOP LEFT	REVERB		SHURE SM57 OR SIMILAR
10.	LESLIE TOP RIGHT	REVERB		SHURE SM57 OR SIMILAR
11.	LESLIE REVERB			SHURE SM57 OR SIMILAR
12.	VOX AMPLIFIER			SHURE SM57 OR SIMILAR
13.	BASS AMPLIFIER			SENNHEISER-421 OR STD BASS MIC
14.	TALKING ANDERS		NONE	STD VOCAL MIC
15.	TALKING STAFFAN		NONE	STD VOCAL MIC
16.	BACKTRACK UNIT	DI-BOX		(STEREO DI-BOX)
17.	INTRO BACKTRACK			(MP3 PLAYER INPUT IN P/A)

PLEASE NOTE

- ALL POWER SOCKETS ON STAGE SHALL BE GROUNDED.
- SIX POWER SOCKETS NEEDED (220V, 50HZ) WITHIN 1.5M FROM ORGAN AND LESLIE.
- TWO POWER SOCKETS NEEDED (220V, 50HZ) WITHIN 1.5M FROM DRUM KIT.
- THE REVERB INSERTS ON CHANNELS 08, 09, 10 CAN BE INSERTED ON THE WHOLE LESLIE MASTER CHANNEL AS WELL

VIDEO INPUT/OUTPUT

IF AGREED THAT VENUE PROVIDES VIDEO PROJECTOR, THE FOLLOWING VIDEO OUTPUT CONNECTIONS ARE COMPATIBLE WITH DVD PLAYER PROVIDED BY ARTIST: – STANDARD LARGE HDMI (DVD COMPATIBLE, I.E. NOT HDMI ADAPTOR TO VGA)

PLEASE NOTE

COMPONENT (R/G/B) CONNECTION IS **NOT** ACCEPTABLE.

COMPOSITE CONNECTION IS **NOT** ACCEPTABLE.

VIDEO PROJECTOR SHOULD SHOW 16:9 RATIO.


ACCEPTABLE SCREEN SIZE IS 3*2 M OR LARGER (DEPENDING ON VENUE).



UPDATED MARCH 22, 2016

STAGE PLOT

REQUIRED STAGE SIZE: ~ 4*3 M



PLACEMENT OF ELECTRICAL POWER SOCKET(S)